









## What do the LEDs on the ADC-V622 mean?

LED pattern	Status	Description
<b>Green   Solid</b> 	Connected to internet	Local network and internet connection with Alarm.com IP.
<b>Green   Flashing</b> 	Local network connection	Local network connection with local IP address, no internet. <b>Note:</b> If the LED does not go to a solid green after a few minutes, see <a href="#">Camera LED is blinking green</a> .
<b>Red   Solid</b> 	No network connection	No local or Internet connection.
<b>Red   Flashing</b> 	System booting	Camera is booting. This typically takes 60-90 seconds.
<b>Blue   Flashing</b> 	WPS mode	WPS mode is active. To enter WPS mode, press the Menu button and use the Volume buttons to scroll to WPS Mode.
<b>White   Flashing</b> 	AP mode	Wi-Fi access point (AP) mode is active. To enter AP mode, press the WPS button for about six seconds.



## LED pattern

## Status

## Description

Yellow | Flashing



Bluetooth pairing

Bluetooth pairing mode is active. To pair with Bluetooth, press the Menu button and use the Volume buttons to scroll to Bluetooth mode.

The camera is restoring to factory default settings.

**Caution:** If the camera is already installed, it may need to be removed from the Alarm.com account and re-added after a factory reset.

Red & Green | Flashing



Factory reset

To perform a factory reset, press the Menu button and use the Volume buttons to scroll to the Factory Reset option. Follow the audio prompts to initiate a factory reset.

