

Slim Line Doorbell Camera

LED and Troubleshooting Reference Guide



LED Pattern Key



Normal Operation



Ready and working normally

Use the Alarm.com app or Customer Website to choose a custom color in place of default green.



In Call mode

A call has been initiated or is occurring.



Starting up

Please wait while the doorbell is booting up.



Battery is charging

Battery may charge for ~30 minutes after installation.



Connected to Wi-Fi, waiting for server connection

Please wait.



Firmware update in progress

Please wait.

Requires Attention



No Wi-Fi connectivity

Check your Internet connection. Your Wi-Fi credentials may have changed. Enter Wi-Fi Access Point Mode (see Troubleshooting below) and re-add the doorbell camera using the app.



Power supply issue

Contact your installer. The doorbell transformer may need to be replaced.

Troubleshooting

Press and hold doorbell button for the time shown to perform a troubleshooting step.



Entering Troubleshooting modes

Continue to press & hold for troubleshooting steps below.



Wi-Fi Access Point mode

*Connect to the camera's temporary network and use the app to re-add the camera. **Push & hold ~60 sec until flashing, then release.***



Power cycle

*Reboots the camera. **Push & hold ~70 sec until flashing, then release.***



Factory reset

*Factory resets the camera. Deletes all Wi-Fi and configuration information. **Push & hold ~80 sec until flashing, then release.***